



M24 BB30/PF30

68MM ROAD OR 73MM MTN

**For Praxis M24 MTN/Road Cranks
and SRAM GXP™ Cranksets**

SAFETY INFORMATION - READ BEFORE RIDE

Since specific tools and experience are necessary for proper installation, it is recommended that the product be installed by a qualified bicycle technician.

Read the service instructions of your crank carefully prior to installing the parts. Loose, worn or damaged parts may cause riding problems and serious injury may occur as a result. If installation and adjustments are not carried out correctly, the chain may come off and this may cause you to fall off the bicycle which could result in serious injury. **Read these instructions carefully, and keep them for later use.**

- Ensure that your BB30/PF30 frame shell is clean. Remove the c-clips/bearings for BB30 frame shell.
- Conversion BB - Make sure the black O-ring is on the Non-Drive Cup prior to pressing into Non-Drive side.
- Apply **Anti-Seize** to the drive cup threads and smooth taper area before installing.
- Before riding the bicycle, check that there is no play or looseness in the bottom bracket connection. Also, be sure to retighten the crankarms and pedals at periodic intervals.
- If you feel any looseness or 'play' in the bearings, the bottom bracket should be inspected/replaced.
- Be sure to read the instructions for your front chainrings/crank in conjunction with these service instructions.
- **Do not wash the bottom bracket with high-pressure jets of water.**
- For maximum performance it is required to remove and periodically inspect/clean your Praxis Works bottom bracket.
- **Parts are not guaranteed against natural wear or deterioration resulting from normal use.**
- For any questions regarding methods of installation, adjustment, maintenance or operation, please contact a professional bicycle dealer or call Praxis Works.
- Praxis Works assumes no responsibility for damages or injury related to improperly installed components.

READ THE STEP BY STEP INSTRUCTIONS PROVIDED ON THE OTHER SIDE.

WARRANTY

- Praxis Works Bottom Bracket products are warranted to be free from defects in materials or workmanship for two years after original purchase. The warranty is non-transferable and valid to the original purchaser of the product only.
- Any attempt to modify the product in any way such as drilling, grinding or painting will void the warranty.
- This warranty is not valid for "abused" or neglected products, or products that are damaged by improper installation.
- If a defect is found, our entire liability and your sole remedy shall be, at our option, free repair or replacement of the Praxis product.
- Except as expressly required by law, Praxis Works shall not be held liable for any indirect, special, or consequential damages.

THIS WRITTEN EXPRESS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, IMPLIED OR EXPRESSED. This warranty gives you specific legal rights, and you may also have other rights which vary state to state. **For more information on warranty policy and instructions for completing a warranty claim, check out the Full Warranty Policy found at our website. www.praxis-works.com**

M24 BB BB30/PF30 | Compatibility and Spec


CRANKSET	Compatible with Praxis M24 MTB or ROAD Cranksets and SRAM GXP™ Cranksets 73mm for MTB Cranks only - 68mm for Road Cranks only
FRAME SHELL	Only for BB30, PF30, and Specialized OSBB Frames
FRONT DERAILLEUR	Braze-on, Clamp-on, Direct Mount

REQUIRED TOOLS

- Press Tool
- BB tools for 16-notch 44mm outboard BB cups
- Two 3/8" Drive Ratchets
- Headset cup removal tool
- Anti-Seize
- Waterproof Grease

Included Parts


Number	Part	Qty
1.	22mm ID X 1.7mm Dust Cover	1
2.	LEFT/NON-DRIVE Cup 22mm ID Bearing	1
3.	Width Tolerance O-Ring	1
4.	Delrin PF Sleeve (used on PF frames)	1
5.	Orange Rubber Collet	1
6.	Black Plastic Compression sleeve	1
7.	RIGHT/DRIVE Cup 24mm ID Bearing	1
8.	24mm ID X 2mm Dust Cover	1
9.	24mm ID X 3.7mm Dust Cover	1
10.	Wave Washer	1



BB CUP PREPARATION


LEFT/NON-DRIVE CUP

- 1 Make sure Width Tolerance O-ring is on Left/Non-Drive Cup. This is required to accommodate frame BB width variances
- 2 **FOR BB30** - Remove PF Sleeve (not used with BB30). Apply thin coating of **anti-seize** to both ends of the BB cup *contact surfaces and the threads*
- 3 **FOR PF30** - Slide PF Sleeve on. **Grease** both ends of the PF Sleeve *contact surfaces*. Then put **anti-seize** on the inner threads



RIGHT/DRIVE CUP

- 1 Slide the Black Plastic Sleeve and then the Orange Rubber Collet onto the cup. **This is critical to the function of your BB**
- 2 Apply thin coating of **anti-seize** to the Right/Drive cup threads
- 3 Apply thin coating of **grease** to the outside of the Orange Rubber Collet and Black Plastic Sleeve




Next page *INSTALLATION*.....


BOTTOM BRACKET INSTALLATION

- 1 With a press tool, **GENTLY** press the Left/Non-Drive cup into the frame's Left/Non-Drive side until Width Tolerance O-ring just **BARELY** touches the side of frame

DO NOT COMPRESS THE TOLERANCE O-RING.



- 2 Start threading the **Right/Drive Cup** in **CLOCKWISE** with your BB tool. As it threads in, you will feel friction build as the Orange Rubber Collet expands inside the frame. **This is normal. YOU MUST Grab your second BB tool at this point!**



INSTALLATION continued next page...


3



TURN Right/Drive Cup UNTIL IT STOPS. With 2nd BB tool, hold Left/Non-Drive Cup in place while you tighten Drive cup fully. The 2nd tool gives you leverage so you feel when the Drive cup bottoms out on the Non-Drive cup

*The Drive Cup has a machined stop and by design it **MUST** be tightened until it bottoms out on the Non-Drive cup. This precisely sets/stops the Collet expansion.*

4



See next page to find correct Dust Covers for your crank. Lightly grease underside of Dust Covers and place them over bearings **with Praxis logos facing outward**. Now you can install the crank

BB REMOVAL

1 Unscrew the Right/Drive Cup **COUNTER-CLOCKWISE** and remove. **Use one tool to hold the Left side for leverage, and the other to unscrew the Drive cup**

2 Once the Drive Cup is removed, slide a headset cup removal tool through from the drive side and it **will catch outside edge of the Non-Drive cup**

3 Carefully bracing the tool and frame, very gently hammer/tap the removal tool to push the Non-Drive Cup out of frame

We recommend using a 1.5" headset cup removal tool (photo) as it has a wide stance



* CRANK INSTALLATION *

Please see CRANK instructions at www.praxiscycles.com/manuals

BB DUST COVER SETUP

Only 1 cover per side!

**LEFT/NON-DRIVE
22mm I.D.**

(Stepped Cover)



**RIGHT/DRIVE
24mm I.D.**

**RIGHT/DRIVE
Wave Washer**

**NEXT PAGE FOR
M24 DUST COVER GUIDE**

REFERENCE FRAME BB SPECS



BB DUST COVER GUIDE

ROAD M24	WIDTH	M24 CRANK	LEFT 22MM COVER	LEFT CUP SPACER	RIGHT CUP SPACER	RIGHT 24MM COVER
BSA	68	ROAD DM	1.7mm	-	-	2mm
		ROAD NON-DM	1.7mm	-	-	2mm
		SRAM ROAD GxP	1.7mm	-	-	2mm
T47 E.B.	68	ROAD DM	1.7mm	-	-	1mm
		ROAD NON-DM	1.7mm	-	-	1mm
		SRAM ROAD GxP	1.7mm	-	-	1mm
T47 I.B.	85.5	ROAD DM	1.7mm	-	-	1mm
		ROAD NON-DM	1.7mm	-	-	1mm
		SRAM ROAD GxP	1.7mm	-	-	1mm
BB86	86.5	ROAD DM	1.7mm	-	-	2mm
		ROAD NON-DM	1.7mm	-	-	2mm
		SRAM ROAD GxP	1.7mm	-	-	2mm
* BB30/PF30	68	ROAD DM	1.7mm	-	-	2mm
		ROAD NON-DM	1.7mm	-	-	2mm
		SRAM ROAD GxP	1.7mm	-	-	2mm

MTN M24	WIDTH	M24 CRANK	LEFT 22MM COVER	LEFT CUP SPACER	RIGHT CUP SPACER	RIGHT 24MM COVER
BSA	68	GEN1 MTN DM	1.7mm	2.5	2.5	2mm
		GEN1 MTN NON-DM	1.7mm	2.5	2.5	3.7mm
		GEN2 MTN DM	1.7mm	2.5	2.5	3.7mm
		SRAM MTN GxP	1.7mm	2.5	2.5	3.7mm
	73	GEN1 MTN DM	1.7mm	-	-	2mm
		GEN1 MTN NON-DM	1.7mm	-	-	3.7mm
		GEN2 MTN DM	1.7mm	-	-	3.7mm
		SRAM MTN GxP	1.7mm	-	-	3.7mm
T47 E.B.	73	GEN1 MTN DM	1.7mm	-	-	1mm
		GEN1 MTN NON-DM	1.7mm	-	-	3.7mm
		GEN2 MTN DM	1.7mm	-	-	3.7mm
		SRAM MTN GxP	1.7mm	-	-	3.7mm
T47 I.B.	89.5	GEN1 MTN DM	1.7mm	-	-	2mm
		GEN1 MTN NON-DM	1.7mm	-	-	3.7mm
		GEN2 MTN DM	1.7mm	-	-	3.7mm
		SRAM MTN GxP	1.7mm	-	-	3.7mm
BB90	89.5	GEN1 MTN DM	1.7mm	-	-	3.7mm
		GEN1 MTN NON-DM	1.7mm	-	-	6.8mm
		GEN2 MTN DM	1.7mm	-	-	6.8mm
		SRAM MTN GxP	1.7mm	-	-	6.8mm
BB92	92	GEN1 MTN DM	1.7mm	-	-	2mm
		GEN1 MTN NON-DM	1.7mm	-	-	3.7mm
		GEN2 MTN DM	1.7mm	-	-	3.7mm
		SRAM MTN GxP	1.7mm	-	-	3.7mm
* BB30/PF30	73	GEN1 MTN DM	1.7mm	-	-	2mm
		GEN1 MTN NON-DM	1.7mm	-	-	3.7mm
		GEN2 MTN DM	1.7mm	-	-	3.7mm
		SRAM MTN GxP	1.7mm	-	-	3.7mm

"DM" = DIRECT MOUNT SPIDER (Removable Spider)

"NON-DM" = NOT DIRECT MOUNT SPIDER (Pressed-On Spider)